

Cutters for Circular Samples PS

the ideal attachment for the Electronic Precision Balance KS 2000



Reliable determination of weight can only be guaranteed with a specimen of accurate weight per unit area. This is why SCHRÖDER has designed for you the PS Sample Cutter. Sharp cutters moving along a circular path use a drawing action to cut accurate circular samples with smooth edges. Even difficult materials such as fine knits, non-wovens, carpeting, synthetic leather, fleecy or velvet-like materials, thin films, tissue paper, corrugated cardboard, etc. can be cut without effort.

The cut is made on a base of porous rubber. The cutters can cut into this base with complete safety.

Easy manipulation, as compared with die cutters.

Accurate cutting edges assured by circular drawing of razor blades.

Samples are conveniently cut out on rubber pads, one will be supplied with the Sample Cutter.

Replacement set, consisting of

5 rubber pads
100 cutting blades

Standard sizes:	
Model PS 100	for circular samples of 100 cm ²
Model PS 50	for circular samples of 50 cm ²
Model PS 25	for circular samples of 25 cm ²
Model PS 10	for circular samples of 10 cm ²

We produce Sample Cutters PS in any desired size for samples ranging from 35 to 240 mm diameter!